
70x150mm

KWS-2301C产品说明书



产品参数

品称: TYPE-C测试仪产品

1: 电压4-30V

3: 计时0-99小时

5: 容量0-99999MAH

7: 记录单次最高功率

9: 记录单次最高电压 11: CPU温度

10: 电能0-99999WH

12: 产品净重: 7.9G左右

型号: KWS-2301C

8: 记录单次最大电流

2: 电流0-12A

6: 电流方向标

4: 功率0-360W

功能操作

产品背面有一个按键,可以通过按键单击变换显示页面,快速 双击按键可以变换显示方向,长按3秒左右可以清除记的计时 和容量以及电能。

常见问题

问题1:产品为什么插上电产品不显示?


答:type-c口大部分的充电产品是默认没有电压输出的,只有 检测到负载协议时才会有电压输出。

问题2:我的产品充电器上标了10A或120W为什么测试表不能 测出10A或120W?

答:本产品测试出来的数值是充电过程中的实时充电参数,充 电器上标的参数是产品的最大功率参数。

问题3:产品在使用中没有连接负载也会有0.01-0.02A的电流? 答:本产品是采用双向电流检测,出现很小的空载电流属于正 常现象,但也可以通过按键消除,消除方法:确保没连接任何 负载时,按住按键不放再连接带5V的type-c到母座等显示屏出 CAL时再松开按键,机器会进行自动消除空载电流。

KWS-2301C Product Manual



Model: KWS-2301C

2: Current 0-12A

4: Power 0-360W

Product parameters

Product Name: TYPE-C Tester Products

1: Voltage 4-30V

3: Timing 0-99 hours

5: Capacity 0-99999MAH

6: Current Direction Indicator.

7: Record the maximum power recorded. 8: Record a maximum current measurement.

9: Record a maximum voltage at a single point.

10: Electricity 0-99999WH

11: CPU temperature 12: Product net weight: approximately 7.9G.

Functional operation

There is a button on the back of the product that can be clicked to change the display page. Double-click the button to change the display direction. Press and hold for about 3 seconds to clear the recorded timing, capacity, and power.

Frequently Asked Questions

Question 1: Why is the product plugged in and not displayed?Answer: Most charging products with type-c ports have no voltage output by default and only become active when the load protocol is detected.

Question 2: My product charger is marked with 10A or 120W. Why can't the test table detect 10A or 120W?

Answer: The value tested by this product is the real-time charging parameter during the charging process, and the marked on the

charger is the maximum power parameter of the product.

Question 3: Will the product have a current of 0.01-0.02A without connecting to the load during use?

Answer: This product utilizes two-way current detection. It is normal

to have a small current, but it can also be eliminated by pressing the button. Elimination method: Ensure that when no load is connected, press and hold the button and then connect type-c to 5V to the female seat. Release the button when the display screen comes out of CAL, and the machine will automatically eliminate the idle current.